Arduino4HASCO Format

- 1. A stream consists of a series of bits, grouped as four 8-bits words (32 bits in total)
- 2. A stream must start with a 0xcla0cla0 (header) marker
- 3. After the header, the number of events is stated: 0xa0a00000 + hex(number of events)
- 4. For each event:
 - 1. Event ID number: 0xe0000000 + hex(event ID)
 - 2. Timestamp as the time in seconds since "the epoch" (01/01/1970) as a floating point number.
 - 3. 0xd000000 + 1000 times the Photodiode voltage (unsigned integer)
 - 4. 0xd1000000 + 1000 times the Thermistor temperature (Celsius, unsigned integer)
- 5. A stream must end with a 0xb1eb1e0f (footer) marker
- 6. Finally, the checksum represented by the XOR of all the words contained in the stream *except* the checksum. The XOR of *all* the words contained in the stream (*including* the checksum) must be zero.

A stream containing 5 events looks like this:

```
0xc1a0c1a0
                 header
0xa0a00005
                 number of events (5)
0xe0000000
                 event #1
0x53cfc699
                 timestamp
                 1000 * photodiode voltage
0xd0000c26
                 1000 * thermistor temperature
0xd1006b4e
0xe0000001
                 event #2
0x53cfc699
0xd0000c62
0xd1006ab8
                 event #3
0xe0000002
0x53cfc699
0xd0000c08
0xd10069a0
0xe0000003
                 event #4
0x53cfc699
0xd00000c8
0xd10069b4
0xe0000004
                 event #5
0x53cfc699
0xd0000082
0xd10068b0
0xb1eb1e0f
                 footer
0x62247c63
                 checksum
```